
Straightforward installation:

Just connect the ENAiKOON inmarsat-D to VCC and affix it with the included magnetic holders on the roof of your vehicle. That's all.





Please affix the insulation to Ground



brown = Battery positive pole 9V - 32V (terminal 30) yellow = RS-232 input green = Battery negative pole (terminal 31) white = RS-232 output



Please ensure, that there is no material between the ENAiKOON inmarsat-D and the sky that might interfere with the radio transmission, especially metal, water, metallic evaporated windscreen or metallic varnished plastic parts.

Please ensure as well a minimum distance of 1 meter (1 yd) to other antennas mounted to the vehicle (radio antenna, toll collect antenna, car phone antenna etc.).



ENAiKOON GmbH Helmholtzstr. 2–9 10587 Berlin Germany

Tel.: +49 (0)30 / 39747534 Fax: +49 (0)30 / 39747543 service@enaikoon.com

Service hotline: Mon. - Fri., 9:00 - 13:00 and 14:00 - 17:00 CET