



Installation

ENAIK00N locate-19
direct installation to the fuse box

Plug & go



ENAIK00N locate-19 is easy to connect directly to the power supply, simply connect your lead to the main earth depole screw and plug the positive lead/fuse plug into a fitting vacant slot.



Please ensure, that there is no material between the ENAIK00N locate-19 and the sky that might interfere with the radio transmission, especially metal, water, metallic evaporated windcreens or metallic varnished plastic parts.

Please remember whilst installing the unit in your vehicle that top side of the unit is pointing towards the sky.

Please ensure as well a minimum distance of 1 meter (1 yd) to other antennas mounted to the vehicle (radio antenna, toll collect antenna, car phone antenna etc.).

ENAIK00N

ENAIK00N GmbH
Stendaler Str. 26
12627 Berlin
Germany

Service hotline:

Tel.: +49 30 397475-30
Fax: +49 30 397475-40
info@enaikoon.com
www.enaikoon.com

Mon. - Fri., 9:00 - 13:00
and 14:00 - 17:00 CET